

## PASSO

CHIAVE	Ø mm.	MA	MB	WITH.	Ø mm.	SPIRE
DADO / VITE						
5,5	3	0,5	0,35	1/8	3,17	40
7	3,5	0,6	0,35			
7	4	0,7	0,5	5/32	3,97	32
8	4,5	0,75	0,5			
8	5	0,8	0,5	3/16	4,76	24
10	6	1	0,75	1/4	6,35	20
11	7	1	0,75			
13	8	1,25	1	5/16	7,94	18
14	9	1,25	1			
17	10	1,5	1,25 (1)	3/8	9,52	16
19	11			7/16	11,11	14
19	12	1,75	1,25 (1,5)	1/2	12,70	12
22	14	2	1,5	9/16	14,29	12
24	16	2	1,5	5/8	15,87	11
27	18	2,5	1,5			
30	20	2,5	1,5			
32	22	2,5	1,5	3/4	19,05	10
36	24	3	2	7/8	22,22	9
41	27	3	2	1" CH 41	25,40	8
46	30	3,5	2	1" 1/8	28,57	7
50	33	3,5	2	1" 1/4	31,75	7
55	36	4	3	1" 3/8	34,92	6
60	39	4	3	1" 1/2	38,10	6
65	42	4,5	3	1" 5/8	41,27	5
70	45	4,5	3	1" 3/4	44,45	5
75	48	5	3	1" 7/8	47,62	4,5
80	52	5	3	2"	50,80	4,5
85	56	5,5	4			
90	60	5,5	4			
95	64	6	4			

**VI-TOR**  
S.A.S.  
di AVERE & C.



[www.vi-tor.it](http://www.vi-tor.it) e-mail [vitorbulloneria@tin.it](mailto:vitorbulloneria@tin.it)